



OK plug in the cable, and the drivers should install automatically.  
YOU MUST HAVE AN INTERNET CONNECTION.

Windows 8 will start the install:





When it installs the com port number is shown:






If your COM port number is between 1 and 4 that's fine (please make a note of the number). If it's like mine above 1 to 4 (COM 21) then you must change it to a number between 1 and 4. It's done from device manager, I will detail it below.


Open the charm side bar (hold down the 'Windows icon key' key and 'C')





Takes you here:














That's it.

Now for the main program.

Select 'Install VAG VCDS lite' from the main disk menu. It's quite standard stuff so I will just show you the screen shots:







!! PLEASE NOTE YOU WILL GET THIS ERROR MESSAGE IF YOUR NOT CONNECTED TO YOUR CAR WITH THE IGNITION ON !!



Just plug into your car and try again.  
That's it, any problems please email.

NJ Diagnostics [www.obdscanner.co.uk](http://www.obdscanner.co.uk)