


VAG-COM VCDS Cable Driver and Software Installation Guide for Windows 98 and XP


Install the comport drivers from the menu first! Unplug anything using a USB port on your computer!

Plug in the VAG-COM cable and wait for a few seconds until you get the message that it's installed and ready to use.

Next open up control panel: 'START/Control Panel'. If you have the normal view you must set it to classic view:




You will then see this screen:




Double click this icon and you will see this screen:




Click the hardware tab, then the device manager tab:




The Device Manager screen will appear:




Click the + sign next to 'Ports (COM & LPT)' the path will open as below:




Double click the 'USB Serial Port (COM6)' path. NOTE – your com number may not be 6 it may be any number up to 20 it doesn't matter. Then you will see this screen:



Click on port settings, and then the 'Advanced Tab':





From the pull down menu select 'COM 4' and lick 'OK'






Your lead and com port drivers are now installed.

Select 'Install VAG VCDS lite' from the main disk menu. It's quite standard stuff so I will just show you the screen shots:










!! PLEASE NOT YOU WILL GET THIS ERROR MESSAGE IF YOUR NOT CONNECTED TO YOUR CAR WITH THE IGNITION ON !!



Just plug into your car and try again.

That's it, any problems please email.

Thank you